

**KNOW WHERE YOUR LOVED
ONES ARE AT ALL TIMES**



TIGERTRACK
WEARABLE SMART GPS TRACKER
& PANIC BUTTON
WITH BUILT-IN CELL PHONE



TIGERTECH™
THE FUTURE OF SMART



The TigerTrack Smart GPS Tracker Phone is a Stand Alone, wearable Personal Security Device, that combines a GPS Tracker, a Cell Phone with mic and speaker and a Panic button – all in one good looking device.

Multi-mode Tracking: The TigerTrack uses GPS, LBS and WiFi positioning technologies that allows family & friends to track and map movement of loved ones in real-time, anywhere in the world through a Smartphone App.

Panic/SOS Button: In case of an emergency, pressing the Panic button will immediately send alerts along with your exact location to your family and will also automatically dial pre-designated emergency numbers for a 2-way phone call.

One-Way call: Allows you to keep a close watch on care givers if your family member is unwell and your family can also call the Tracker and listen in to the surrounding sounds in case you have any trouble.

Virtual Geofence: Define your safety zones on a map and get instant alerts as soon as the device leaves the designated safety zone or exits any defined boundaries. Perfect for ensuring safety of children, senior citizens, pets & assets

Compact size: 23 grams and 1.5 inches square in size makes it convenient to be worn or carried everywhere.



TIGERTRACK

SMART TRACKER PHONE

Specifications

| Category | Specifications |
|------------------------------|--|
| Dimensions | 38.5X38.5X17mm |
| Weight | 22g without package, 130g with package box |
| Colors | White, Red, Blue |
| SOS Button | One button for Power & SOS calling |
| GPS antenna | Highly Sensitive ceramic active antenna |
| GSM antenna | FPC antenna |
| Battery | 450mAh |
| SIM card slot | 1 pc |
| G-sensor | Supported for speed display |
| I/O port | USB charger port |
| CPU | MTK MT6261 |
| GPS chip | MTK3337 |
| GPRS | Class12 |
| GPS signal | L1,1575.42MHz C/A |
| GPS channel number | 22 channels |
| GPS chip receive sensitivity | Tracking sensitivity - 165dBm, Capture sensitivity:-148dBm |
| GPS location accuracy | 5~15M |
| LBS location accuracy | 100-1000M |
| Minimum standby current | less than 0.5 mA |
| Average standby current | less than 2.5 mA |
| Average working current | around 55mA |
| Working temperature | -20°C to 50°C |
| Working humidity | 5% to 95% non-congealable |
| Test and certification | Approved by 3C, CE & ROHS |
| GPS antenna | Built-in high sensitivity FPC antenna |
| GSM antenna | Built-in four frequency antenna |
| Bluetooth | Bluetooth 3.0(Normal closed) |
| G-sensor | Supported |
| MIC | Built-in |
| Operating Platforms | Android 2.3 and above, IOS5.0 and above. |
| Calling function | 2 way talking, Remote 1 way voice monitoring |
| Language support | English |
| GSM+GPRS+GPS | GPS+LBS+WIFI Multi-modal positioning |
| Support AGPS | Cold start - 26 seconds positioning time |
| Calling functions | SOS call, Voice monitoring, Whitelist for do-not-distured |
| Power management | Ultra-low power consumption, Smart sleep with Auto wake-up on motion |
| One key emergency | SOS button for one key emergency calling, autodialing function |
| Smart Geo-fence | Auto alarm, when device steps outside the set range |
| Route History` | Can check route history for past three months |



PEACE OF MIND... INCLUDED FOR FREE WITH **TIGERTECH**

TigerTech Smart Living Pvt. Ltd

contact@tigertechlabs.com

Call: +91-7720056565

www.tigertechlabs.com



Copyright ©2017 TigerTech Smart Living Pvt. Ltd. All rights reserved. TigerTech, The Future of Smart, the TigerTech logo, Security Anywhere are registered trademarks or trademarks of TigerTech Smart Living Pvt. Ltd. All other names and brands, if mentioned, may be claimed as the property of their respective owners. Any and all specifications mentioned are subject to change without notice.