

**NO POWER? NO WIFI? NO TENSION.  
JUST PLUG IN & GO**



## **TIGER-EYE PLUS**

INDIA'S FIRST 'FAIL PROOF' SECURITY CAMERA

**WORKS ON BATTERY & 3G**

**WITH BUILT-IN SIREN**



**TIGERTECH™**  
THE FUTURE OF SMART



The TigerEye Plus, with **Battery Backup and 3G SIM Card Slot** is the Only Stand-Alone and **Fail Proof** Video Home Security device available.

- **All-in-one Video Security & Monitoring:** Stream 720P HD live video with 4X zoom and 100 degree wide angle, secure your home, receive intrusion alerts, and respond from anywhere
- **Fail Proof:** Built-in Battery backup and SIM Card slot makes it work without Power & Wi-Fi... Perfect for Indian conditions
- **Sensors:** A highly sensitive noise & PIR motion sensor detects intruders and triggers alerts to auto-record video footage
- **Alerts:** Security responses include App notifications, SMS alerts, a phone call from the camera and a video clip sent to your Smartphone in addition to sounding a Siren.
- **Video calling:** Built-in speaker and microphone for 2-way video calling through the App
- **Night vision finally done right:** See & record the entire room clearly at night, in absolute darkness
- **Your Data is Safe:** Secure Streaming with 128-bit encryption and H.264 compression
- **Local storage:** Upto 32 GB SD card records 7 days video using timeline recording allowing quick search & review
- **Easy to install:** Can be shelf or wall mounted with absolute ease



720P  
HD VIDEO



2 WAY  
AUDIO



LIVE  
STREAM



NOISE &  
MOTION  
DETECTION



NIGHT  
VISION



SD CARD &  
CLOUD  
RECORDING



BUILT-IN  
SIREN



# TIGER-EYE PLUS

## FAIL PROOF SECURITY CAMERA

### General Specifications

CPU	Quad Core 1.2GHz CPU
Image Sensor	Megapixel CMOS Sensor
Image Resolution	720P (1280*720), 640*352
Camera Lens	Aperture F2.2, 110 degree wide angle
Video Compression Format	H.264
Video bitrate	Dynamic VBR 0 - 1 Mbps self-adaption
FPS	Max 30 fps
Audio working mode	2-way Talk
Audio Format	G711A (16bit / 8KHz)
Network Interface	WiFi, 3G (WCDMA Band 1, 2, 5, 8)
Connection Options	P2P, WLAN
Memory	TF Card (Max 32GB)
Working Status Indicator	Three Color LED Indicator Light
On-Demand Pictures	Supported
Infra Red Sensor	Supported
PIR	Supported
Motion Detection Alarm	Push Alert with Video Recording, SMS, Phone Call
Platforms Supported	Android / IOS
Max Terminal Number	10
Working Temperature	-20C to 50C, Humidity<95%
App Updates	OTA (Internet) or TF Card
Security Setting	128 bit AES Password Login
Power Consumption	<5W
Battery	5V / 2A
Dimensions	127 (with base) * 41 (Diameter) mm





**PEACE OF MIND... INCLUDED FOR FREE WITH **TIGERTECH****

TigerTech Smart Living Pvt. Ltd

[contact@tigertechlabs.com](mailto:contact@tigertechlabs.com)

Call: +91-7720056565

[www.tigertechlabs.com](http://www.tigertechlabs.com)



Copyright ©2017 TigerTech Smart Living Pvt. Ltd. All rights reserved. TigerTech, The Future of Smart, the TigerTech logo, Security Anywhere are registered trademarks or trademarks of TigerTech Smart Living Pvt. Ltd. All other names and brands, if mentioned, may be claimed as the property of their respective owners. Any and all specifications mentioned are subject to change without notice.